

Gerry's Fishing: DTF Iron-On Guide

Applying a Direct-to-Film (DTF) transfer at home is simple, provided you follow these steps carefully. Since household irons lack the consistent pressure of a heat press, 'heavy pressure' is the key to success.

Step-by-Step Instructions

1. Setup: Use a hard, flat surface (wooden table or countertop). Turn OFF all steam functions. Set iron to 'Cotton' or High (150-160°C).
2. Prep: Iron the hoodie for 5 seconds to remove moisture and wrinkles.
3. Positioning: Place the transfer white-side down. Cover the entire design with parchment (baking) paper.
4. The Press: DO NOT SLIDE. Press down with your full body weight for 15-20 seconds per area. Ensure every part of the design is heated.
5. The Cold Peel: Let the design cool COMPLETELY (1-2 minutes) before slowly peeling away the clear film.
6. Finishing: Place the parchment paper back over the design and press for another 10 seconds to 'set' the ink into the fabric.

Quick Specifications

Requirement	Setting
Iron Temp	150-160 deg C (No Steam)
Pressure	Heavy (Body Weight)
Peel Temperature	Completely Cold

Liability Disclaimer

This guide is provided for informational purposes only. Results may vary based on equipment and technique. Gerry's Fishing accepts no liability for any damage caused to garments, transfers, or property during application. Users proceed at their own risk.